

## Weather Resist Soft Shell Ladies' Jacket



Eddie Bauer<sup>®</sup>, the owner of the EDDIE BAUER trademark, reserves the right to prohibit the addition to any Eddie Bauer<sup>®</sup> product of any mark, name, design, or logo that does not meet the high standards of the brand. Please contact your sales representative with questions. The Eddie Bauer<sup>®</sup> logo is the registered trademarks of Eddie Bauer<sup>®</sup> Licensing Services LLC. These products may not be resold without embellishment.

7686C

Due to the nature of polyester, special care must be taken throughout the decoration process.

Black 6C

## \* Please refer to order grid for available colour selection. Limited to stock on hand. No returns.

## EB539 - Eddie Bauer® Weather Resist Soft Shell Ladies' Jacket

GARMENT MEASUREMENTS										
Size	XS	S	м	L	XL	2XL	3XL	4XL		
Chest - Half Measure	17 3/4"	18 3/4"	19 3/4"	21 1/4"	22 3/4"	24 1/4"	26 1/4"	28 1/4"		
Chest - Full Measure	35 1/2"	37 1/2"	39 1/2"	42 1/2"	45 1/2"	48 1/2"	52 1/2"	56 1/2"		
Body Length from HPS (At Front)	25 1/4"	25 7/8"	26 1/2"	27 1/8"	27 3/4"	28 3/8"	29"	29 5/8"		
Body Length from HPS (At Back)	26 1/4"	26 7/8"	27 1/2"	28 1/8"	28 3/4"	29 3/8"	30"	30 5/8"		
Sleeve Length-CB	31 3/4"	32 1/4"	32 3/4"	33 3/8"	34"	34 5/8"	35"	35 3/8"		

Finished measurements in inches. Refer to "How to Measure" guide for detailed information on measurement instructions.

LADIES' General Sizing Guide										
Size	XS	S	м	L	XL	2XL	3XL	4XL		
Numeric Size	2	4-6	8-10	12-14	16	18-20	22	24		
Bust	32"-34"	35"-36"	37"-38"	39"-41"	42"-44"	45"-47"	48"-51"	52"-55"		
Waist	24"-25"	26"-27"	28"-30"	30"-32"	33"-35"	36"-38"	40"-42"	42"-44"		
Hip	33"-35"	35"-37"	37"-39"	39"-41"	42"-44"	45"-47"	48"-50"	50"-52"		
Sleeve Length-CB	30"-30 1/2"	30 1/2"-31"	31 1/2"-32"	32 1/2"-33"	33 1/2"-34"	34"-34 1/2"	34 1/2"-35"	34 1/2"-35"		



## **DECORATING INSTRUCTIONS FOR POLYESTER SOFT SHELL JACKETS**

Due to the nature of polyester, special care must be taken throughout the decoration process. Here are some tips to effectively decorate polyester soft shell products:

- Garment temperature must not exceed 320°F or 160°C. Exceeding this temperature will cause the fabric to shrink, become wavy or cause dye migration.
- Dryer temperature and belt speeds must be changed accordingly for polyester fabric.
- If flashing these garments, do not exceed 1-2 seconds. Anything longer may damage the fabric as stated above.

**Screen Printing:** These garments require the use of poly inks that cures at a lower temperature. A Dyno Grey base blocker on all colours and a second white base blocker on all dark colours are recommended. Please consult your ink supplier for more information.

 Polyester requires a longer cooling time than cotton. Avoid overlap of garments and screen-print/heat transfer until the garments are cooled. Failure to cool the fabric prior to stacking into a printer's fold may cause the fabric and applied ink to stick together.

**Heat Transfers:** Poly mark heat transfers need to be created with an anti-migration layer in the design. This process can only be done on white or very light colour shirts. Inks used in printing paper design needs to be darker than the base fabric or colour will migrate with the fabric colour resulting in a bleeding effect.

A test sample run is recommended, especially if you have a large order or if your printer does not specialize in printing on polyester fabrics.